

9402	37890	Fuel_Gauging
9403	37891	Brake_Fluide_Level
9404	37892	Warning Airbag Telltale monitoring
9408	37896	Seat belt telltale command monitoring (external telltale)
940C	37900	EEPROM monitoring
9411	37905	Oil Pressure Input
9412	37906	External Temperature Inputs
9413	37907	Error Configuration
C001	49153	Lost CAN communication
F003	61443	Power Supply monitoring