

218	536	GB Overheating
571	1393	Brake pedal coherency
603	1539	E2PROM
604	1540	RAM
605	1541	Checksum
615	1557	Clim/Key-lock Fault
641	1601	Sensors Feed
657	1623	SSV Supply Fault
705	1797	MFS: prohibited position
706	1798	MFS: intermediate position
709	1801	MFS: affected by interference
710	1808	Oil temperature sensor
715	1813	Turbine speed fault
720	1824	Vehicle speed sensor
730	1840	Cylinder slip
740	1856	Lock-up
753	1875	SSV1 failure
758	1880	SSV2 failure
763	1891	SSV3 failure
768	1896	SSV4 failure
773	1907	SSV5 failure
775	1909	MSV failure
795	1941	LUSV failure
814	2068	Display failure
819	2073	Flick-shift contacts fault
826	2086	Steering wheel gearswitch contacts
840	2112	Pressure sensor
841	2113	Line pressure failure
850	2128	P/N contact failure
851	2129	P contact failure
894	2196	Receiver slipping
170D	5901	Air to oil fan
1928	6440	Shift lock failure
2709	9993	SSV6 failure
2753	10067	FCSE failure
2805	10245	S2 S3 MFS failure
C001	49153	CAN transmission
C100	49408	Link to engine management system computer
C121	49441	Lost communication with ABS control module
C140	49472	Lost communication with BCM
C155	49493	Lost communication with IPC
D100	53504	Coolant temperature not sent by engine management
D11F	53535	Engine speed not sent by engine management
D120	53536	Expected torque not sent by engine management
D121	53537	Raw pedal position not sent by engine management
D122	53538	Actual torque not sent by engine management
D123	53539	CAN torque setting state
D126	53542	Torque request acknowledgement fault
D12B	53547	Torque without GB reduction
D12C	53548	Min instantaneous torque not sent by ECM
D12D	53549	Max instantaneous torque not sent by ECM
D12F	53551	Driver request not sent by engine management
D200	53760	Vehicle speed not sent by ABS
D220	53792	Front Right wheel speed not sent by ABS
D221	53793	Front Left wheel speed not sent by ABS
D225	53797	Rear Right wheel speed not sent by ABS
D226	53798	Rear Left wheel speed not sent by ABS
D403	54275	BCM brake fault