

Код	Расшифровка (англ.)	Расшифровка (рус.)
P0100	Mass airflow sensor/circuit	Датчик массового расхода воздуха
P0110	Intake air temperature	Датчик температуры воздуха на впуске
P0115	Coolant temperature sensor	Датчик ТОЖ
P0115	Coolant temperature sensor out of range	Показания датчика ТОЖ вне изм.диапазона
P0120	Throttle position sensor (TPS)	Датчик положения дроссельной заслонки
P0130	Oxygen sensor	Датчик кислорода
P0130	Closed loop operation	Цепь переднего датчика кислорода
P0135	Front oxygen sensor heater problem	Подогрев переднего датчика кислорода
P0136	Rear oxygen sensor problem	Задний датчик кислорода
P0170	Fuel injection system problem	Проблемы системы впрыска топлива
P0300	Random misfire	Пропуски зажигания в разных цилиндрах
P0301	Misfire on cylinder 1	Пропуски зажигания в 1 цилиндре
P0302	Misfire on cylinder 2	Пропуски зажигания в 2 цилиндре
P0303	Misfire on cylinder 3	Пропуски зажигания в 3 цилиндре
P0304	Misfire on cylinder 4	Пропуски зажигания в 4 цилиндре
P0325	Knock sensor	Датчик детонации
P0335	Crankshaft position sensor signal problem	Датчик положения коленвала
P0340	Camshaft position sensor / circuit	Датчик положения распредвала
P0400	EGR function	Неисправность ERG(система рециркуляции выхлопных газов)
P0420	Catalytic converter system problem	Проблемы катализатора
P0500	Vehicle speed sensor	Датчик скорости
P0605	ECM control unit	Ошибка ПЗУ
P1320	Ignition signal	Зажигание первичная цепь
P1336	Crank P/S COG	Зуб ДПКВ
P1401	Exhaust gas temperature sensor	Датчик температуры ERG(система рециркуляции выхлопных газов)
P1402	EGRC-BPT valve problem	Клапан ERG(система рециркуляции выхлопных газов)
P1605	A/T diagnostic communications line	Проблемы связи в блоком управления АКПП
P1900	Overheat condition	Перегрев

11	0340	Camshaft Position Sensor
12	0100	Mass Airflow Sensor
13	0115	Engine Coolant Temperature Sensor
14	0500	Vehicle Speed Sensor
21	1320	No Ignition Signal
22		Fuel ump.
23		Idle Switch
24		Throttle Valve Switch.
25	0505	Idle Air Control Valve (IACV-AAC)
28 (1)	1900	Cooling Fan Circuit (Overheat)
31	0605	ECM Malfunction
32	0400	EGR Malfunction
33	0130	(2) Front Heated Oxygen Sensor
34 (3)	0325	Knock Sensor
35	1401	EGR Temperature Sensor
36	0402	EGR Backpressure Transducer
37	0130	Closed Loop
38		Right hand bank Closed Loop (B2).
41	0110	Air Temperature Sensor
42		Fuel Temperature Sensor
43	0120	Throttle Position Sensor
45		Injector Leak.
46		Crankshaft Position Sensor
51		Injector Circuit.
53		Oxygen Sensor.
54		A/T Control

55	0000	No Malfunction Recorded
63		No. 6 Cylinder Misfire.
64		No. 5 Cylinder Misfire.
65	0304	No. 4 Cylinder Misfire
66	0303	No. 3 Cylinder Misfire
67	0302	No. 2 Cylinder Misfire
68	0301	No. 1 Cylinder Misfire
71	0300	Multiple Cylinder Misfire (Random)
72	0420	Catalyst Malfunction
73		TWC Function right hand bank.
76	0170	Fuel Injection System Malfunction
77	0136	Rear Heated Oxygen Sensor
82	0335	Crankshaft Position Sensor
84	1605	A/T Diag Comm Line
85	1110	VTC Solenoid Valve
86		Fuel Injection System Function right hand bank.
87		Canister Control Solenoid Valve Circuit.
91	1350	Front Heated Oxygen Sensor
94	1550	TCC Solenoid Valve
95	1336	Crankshaft Position Sensor
98	0125	Engine Coolant Temperature Sensor
101		Front Heated Oxygen Sensor Heater Circuit right hand bank.
103	0705	Inhibitor/Neutral Position Switch
105	1400	EGR & Canister Control Valve
108		Canister Purge Control Valve Circuit.
111	0705	Inhibitor Switch (4)
112	0720	Vehicle Speed Sensor A/T (4)
113	0731	A/T 1st Signal (4)
114	0732	A/T 2nd Signal (4)
115	0733	A/T 3rd Signal (4)
116	0734	A/T 4th Signal or TCC (4)
118	0750	Shift Solenoid/V A (4)
121	0755	Shift Solenoid/V B (4)
123	1760	Overrun Clutch Solenoid Valve (4)
124	0740	Torque Converter Clutch Solenoid Valve (4)
125	0745	Line Pressure Solenoid Valve (4)
126	1705	Throttle Position Sensor A/T (4)
127	0725	Engine Speed Signal (4)
128	0710	Fluid Temperature Sensor (4)

(1) - GST only.

(2) - Manual transmission, except California emissions vehicles, does not use heating element.

(3) - MIL will not light for knock sensor malfunction.

(4) - Automatic Transmission only.