

A4A0	42144	EEPROM
A4A1	42145	VBatt
A4A2	42146	Config
A4A3	42147	AQS_Reductor
A4A4	42148	EvapTemp
A4A5	42149	AQS_Oxydant
A4A6	42150	InCarTemp
A4A7	42151	AQS_Supply
A4A8	42152	AQS_PreHeating
A4A9	42153	Heated_Seat_RR_Feedback / Sensor_Sunload
A4AA	42154	Heated_Seat_FL_Feedback / Sensor_2nd_Sunload
A4AB	42155	HumiditySensor
A4AC	42156	AQS_PWM
A4AD	42157	RearMixActr
A4AE	42158	Hot_Source / Blower_Fan_Feedback
A4B1	42161	Heated_Seat_FR_Feedback
A4B2	42162	AQM_IonizerMode
A4B3	42163	Heated_Seat_RL_Feedback
A4B4	42164	FrontControlPanel
A4B5	42165	Blower_BatFan_Feedback / Rear_Switch/Boiler_Feedback
A4B6	42166	CentralPanel
A4B7	42167	Motor1Actr
A4B8	42168	RearAirTempSensor
A4B9	42169	Motor2Actr
A4BB	42171	Motor3Actr
A4BD	42173	Motor4Actr
A4BF	42175	Motor5Actr
A4C1	42177	Motor6Actr
A4C3	42179	BlowerSystem1
A4C6	42182	BlowerControl
A4C7	42183	Heated_Seat_FR_CMD / BatFan_PWM /Rear_Fan_CMD
A4C9	42185	Heated_Seat_FL_CMD /Relay_Control_Output/Boiler_CMD
A4CB	42187	Heated_Seat_FL_CMD_LED / Comp_Valve_output
A4CD	42189	BatteryBlowerSystem1
A4CF	42191	Cabin_Cool_Valve_output
A4D1	42193	Battery_Cool_Valve_output
A4D3	42195	LIN_Bus
A4D4	42196	LIN2_Bus
A4D5	42197	RearControlPanel
A4D7	42199	RearBlowerFanFeedback
A4D8	42200	AQMControlPanel
A4DA	42202	AQM_FragranceMotor
A4DC	42204	AQM_FragranceBlower
A4DE	42206	AQM_Ionizer
A4E0	42208	RearDistActr
A4E1	42209	Rear_Hot_Blower_PWM
A4E3	42211	Rear_Cold_Blower_PWM
A4E5	42213	Heated_Seat_FR_CMD_LED / Windshield_Defroster_Right
A4E7	42215	Wipers_Defroster_ /Windshield_Defroster_Left
A4E8	42216	BlowerByLin
D000	53248	CAN Communication
D010	53264	CAN Self Diag